

## Set up

Open the package

Locate a clean, flat area in diameter that is free of hard obstructions, abrasive materials, and sharp objects. Carefully spread out.



## Inflate

Inflate with the pump insert to valve. Use the included manometer to check correct working pressure. Check the manometer and use hand to press the product to feel pressure.



Turn on the switch to inflate



Find the valves



Manometer to check the pressure



Turn off the valves




Turn off switch

## Fixed

Vertical anchor,ensure the minimum water depth is maintained.

Use a concrete block, tire anchor, barrel anchor etc as an attachment point.



## Finished

## Website:

<http://www.inflatablechina.com>

<https://barryinflatables.en.alibaba.com/>

<https://barry.en.alibaba.com/>

<http://www.inflatable-toy.com/>

<http://www.reapwaterpark.com/>